

FZW-1 Wiring Harness Installation Instructions



Packing List:

- 1 12GA 6FT Black wire with ring terminal
- 1 12GA 6FT Red wire with ring terminal and 30A inline fuse holder
- 1 18GA 6FT Yellow wire with 3A inline fuse holder
- 1 6FT wire harness braiding
- 1 Posi-Tap (<http://www.posi-lock.com/posiplug.html>)

Connect the FZW-1 wiring harness using the below diagram. Be sure to use the braiding including for the wiring harness as much as possible to protect the wiring from rubbing against any sharp surfaces that may possibly cause a short or wear and tear on the wiring.

J1 Connections on FZ-1 Fuzeblock

- +12V: Red wire to positive terminal of battery
- +VT: Yellow wire to Posi-Tap to +12V switched wire
- GND: Black wire to negative terminal of battery

